

**Miele**

**NEW**

The new ProfiLine dishwashers from Miele  
Efficient dishwashing several times a day

**Miele Professional. Immer Besser.**



**ProfiLine**

# Built to meet the highest demands on performance and design

Dishwashers for up to 5 cycles per day



## **Frequent dishwashing, huge mountains of crockery**

Breakfast, lunch, meetings, appointments with customers, events – in many companies, there is no end of events where large quantities of crockery needs to be washed and ready for use in next to no time. Whether in office kitchens in company headquarters, legal practices or agencies, in showrooms, clubhouses or kitchen studios – with their short cycle times, ProfilLine dishwashers represent the professional solution for routinely spotless results - all with the familiar convenience from a domestic dishwasher.



Miele Professional is a decision in favour of top performance, quality and efficiency. High-quality machines which reliably meet the expectations of the discerning, day in and day out, underline the trust placed by commercial users in Miele: 97% of all clients\* would buy from Miele again next time round.

The flexible basket design and special programmes guarantee the perfect gentle care of crockery and glassware. Riedel 'THE WINE GLASS COMPANY' recommends Miele dishwashers.



## Dependability

As a family-run company, now in its fourth generation, our actions, as always, still stem from a sense of responsibility for our products and processes and towards our employees, business associates and the environment.

- Product development with a clear focus on quality, durability and sustainability
- Innovations 'Made in Germany' which have set their stamp on the industry
- Award-winning ergonomics, functionality and product design
- Entire system from one single source
- Lower operating costs over entire product life cycle (Total Cost of Ownership)
- Highly commended after-sales service offering blanket coverage and a fast response





# ProfiLine dishwasher highlights



## Very short cycles

Are very short cycle times and sparkling results important to you? In this case, the new ProfiLine dishwashers are the perfect choice: Connections for hot water and a single phase supply, intelligent dishwashing technology and a powerful heater pump ensure the shortest possible cycle times, starting at only 29 minutes, combined with optimum cleaning results. Take advantage of innovative features that make your crockery sparkle day after day in the shortest amount of time.



## Convenient connectivity

How about saving time to concentrate on more important jobs? No problem! Networking your new ProfiLine dishwasher opens up innovative opportunities which offer greater convenience, quality of life and security in the hustle and bustle of commercial life. With the aid of the free Miele app\* [mielepro@mobile](mailto:mielepro@mobile), you are in a position to communicate with your machine from anywhere and at any time to control programmes, check up on remaining programme times or monitor supplies. It only takes a few clicks to conveniently order dishwasher tablets and other supplies from your smartphone or tablet PC.

\*Minimum requirements: Android 4.2+ / iOS 9+



## Maximum flexibility

Thanks to an extremely flexible basket design, glasses, crockery and cutlery are perfectly cleaned. FlexAssist colour coding indicates at a glance which elements allow baskets to adapt to individual needs. FlexCare glass holders accommodate stemware securely in the basket. This guarantees perfect and gentle cleaning.



## Low consumption

The environmentally friendly way of cutting costs: ProfiLine dishwashers with their low consumption are convincing and known for their maximum efficiency. The aim at the product design stage is to achieve perfect dishwashing results by using recyclable materials and no more water, energy and detergent than is absolutely necessary.

# Further benefits of the new ProfiLine dishwashers\*

\* model-dependent



## Best sound emissions

The new ProfiLine dishwashers generate low sound emissions of 45 dB(A) and are therefore particularly quiet and produce consistently excellent results. This is even significantly quieter than a normal conversation.



**Exclusive  
to Miele**

## Patented<sup>2)</sup> AutoOpen function

With enhanced drying selected, the dishwasher door opens automatically to the ajar position at the end of a programme. This allows fresh air to reach the crockery, ensuring that even plastic dishes dry completely. Special air ducting protects the worktop from moisture.

<sup>2)</sup> European patent EP 1 080 681



**Exclusive  
to Miele**

## Perfect GlassCare<sup>3)</sup>

Soft water will clean crockery thoroughly but has an aggressive effect on glass. Consequently, ProfiLine dishwashers are equipped with Perfect GlassCare<sup>1)</sup> technology. This feature ensures that the water used has the correct mineral content.

This helps protect glassware and keeps stemware looking as good as new.

<sup>3)</sup> European patent EP 1 457 153 B



### **Superb hygiene**

In office kitchens available to staff and visitors, hygiene must be high on the agenda. The new ProfiLine dishwashers operating on the fresh water principle achieve extremely hygienic results thanks to their high main wash and rinse temperatures, particularly in the 'Hygiene' programme.



**Exclusive  
to Miele**

### **ComfortClose**

Practical: the door is extremely easy to open and close, and stays open in any position.



**Miele**  
PROFESSIONAL

10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

① ● | V



# ProfiLine dishwashers

## Product overview

### Note:

In view of the need for higher final rinse temperatures and improved hygiene Miele advises child-care centres, schools, nursing homes and restaurants to opt for PG 8059 commercial dishwasher from Miele Professional.



Model/sales designation	PG 8130	PG 8130 i
<b>Power output</b>		
Max. cycles per day	5	5
'Short' cycle duration in mins.	29	29
<b>Design</b>		
Fascia panel version/Control type	Straight fascia/programme selector	Straight fascia/programme selector
Display	1-line text display	1-line text display
<b>Convenience</b>		
ComfortClose	●	●
Liquid dispensing with G 80 ProfiLine DOS module possible (optional accessory)	●	●
Sound emissions dB(A) re 1 pW	45	45
Countdown indicator, 24 h delay start	●/●	●/●
Functional indicators	Display	Display
<b>Efficiency and sustainability</b>		
Water consumption in l/Energy consumption in kWh (in ECO programme)	16.1 l/0.85 kWh	16.1 l/0.85 kWh
FlexiTimer with EcoStart	●	●
<b>Quality of results</b>		
Fresh water dishwasher/AutoOpen drying	●/●	●/●
Recirculation Turbothermic drying/Perfect GlassCare	●/●	●/●
<b>Dishwashing programmes</b>		
No. of dishwashing programmes	8	8
Intensive cleaning	Intensive 75°C/Hygiene 60°C	Intensive 75°C/Hygiene 60°C
Fast, simple cleaning	Short 70°C/Medium 65°C	Short 70°C/Medium 65°C
Gentle cleaning of glassware	Glassware 50°C	Glassware 50°C
Label programme	ECO 50°C	ECO 50°C
Programmes for special applications	Cold/pre-wash, Plastics	Cold/pre-wash, Plastics
<b>Basket design</b>		
Cutlery position	Cutlery basket	Cutlery basket
Basket design with FlexCare glass holders	MaxiComfort/4	MaxiComfort/4
No. of place settings	13	13
<b>Networking</b>		
Mielepro@mobile/WiFiConn@ct	●/●	●/●
<b>Safety</b>		
WaterProof System/Door locking option	●/●	●/●
<b>Electrical connection</b>		
Mains connection	1N 230V 50 Hz 16A	1N 230V 50 Hz 16A
Heater rating in kW / Fuse rating	3.1 / 16 A	3.1 / 16 A
Convertible by Miele Service, chargeable	1N AC 230V 50 Hz 10A	1N AC 230V 50 Hz 10A
Cold or hot water (15°C - 60°C)	●	●
<b>Design / Dimensions / Weights</b>		
Model range (combinable)	ProfiLine	ProfiLine
Can be installed as	Freestanding unit with worktop	Undercounter/integrated unit
Plinth return (mm)	-	30-95
Supplied with/Front colour/Side panels	With lid/white/white	Without lid/CleanSteel/galvanised
Ext. dimensions H/W/D [mm]/Weight, net [kg]	845/598/600/69	805/598/570/59





**Miele Australia Pty Ltd**

1 Gilbert Park Drive  
Knoxfield VIC 3180  
Australia  
Telephone: 1300 731 411

**Miele New Zealand Limited**

8 College Hill, Freemans Bay  
Auckland 1060  
New Zealand  
Telephone: 0800 464 353

[info@miele-professional.com.au](mailto:info@miele-professional.com.au)

[www.miele.com.au/professional](http://www.miele.com.au/professional)

**Immer Besser (Forever Better)**

Since 1899, Miele - a family-run company - has subscribed to a clear corporate philosophy condensed into the two words 'Forever better'. This overarching claim is the foundation of Miele's proverbial quality and sustainability and the power of innovation of a brand 'Made in Germany'. A brand promise which gives commercial users the certainty of having chosen the right product.

**Award-winning**

Uncompromising product reliability and service dependability is the reason why customers have repeatedly voted Miele the best and most trustworthy brand. Coveted awards such as the MX Award, the iF and reddot Design Awards and the German Sustainability Prize confirm the distinguished position Miele enjoys with respect to design, quality management and the sparing use of resources.

**Proficient**

Miele Professional has been developing and manufacturing a broad range of high-quality laundry machines, dishwashers and lab washers for decades. Carefully selected accessories, comprehensive advisory services and a Miele factory service operation which guarantees a fast response and ensures that machines perform to perfection and offer the ultimate in performance and efficiency.